



*51529 Birch Street  
New Baltimore, MI 48047  
Phone 586-725-0192 Fax 586-725-2225*

## **Carbon Canister Installation instructions**

1. Shut down side access blower system.
2. Open side access housing door.
3. Lay canister holding frame face down on a flat surface with the edges of the frame facing up.
  - a. Leave a minimum of ½" gap between the holding frame and the table.
    - i. This allows canister pins to move freely without binding with the table.
4. Place the canister into the tear drop slots in the holding frame.
5. Place the canister wrench into the wrench locator holes on the back of the canister. Using a little pressure turn the wrench clockwise until the canister stops and seats itself into the small narrow part of the tear drop.
  - a. Make sure to keep the canister perpendicular to the holding frame when turning.
  - b. Do not use excessive force to turn the canister.
  - c. To make installation easier a small amount grease may be applied to the gasket of the canister.
6. Repeat for all canisters until the holding frame is full.
7. Carefully lift the holding frame and slide it into the side access housing tracking.
  - a. Do not lift the holding frame by the canisters. Lift the holding frame by the frame itself.
  - b. Use caution – holding frame will be heavy.
8. Once side access housing is full close the door and turn the system back on.



*51529 Birch Street  
New Baltimore, MI 48047  
Phone 586-725-0192 Fax 586-725-2225*

## **Carbon Canister Removal Instructions**

1. Shut down side access blower system.
2. Open side access housing door.
3. Carefully slide canister holding frame out of housing and place on a flat surface with canisters facing up.
  - a. Holding frame may want to tip once it is free from housing tracking.
  - b. Use caution – holding frame will be heavy.
4. Place the canister wrench into the wrench locator holes on the back of the canister. Using a little pressure turn the wrench counter clockwise until the canister comes free from the holding frame.
  - a. Keep the wrench perpendicular to the canister when turning.
  - b.  $\frac{1}{4}$  of a turn is all that is needed to free the canister from the keyway.
  - c. Repeat for all canisters.
5. Wipe canister holding frame down to remove any dirt or debris.